


TRANSFORMER  
TRANS2008  
(REPLACEMENT PART)



**AVAILABLE PARTS ARE:**  
 PUMP1012 (PUMP)  
 TRANS2008 (TRANSFORMER)  
 BULB3004 (BULB)  
 FTNBLBSHLD (BULBSHIELD)

MODEL: 50281SL

# **ASSEMBLY INSTRUCTIONS**

**READ AND SAVE THESE INSTRUCTIONS**

**READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.**

**THIS FOUNTAIN SHOULD TAKE APPROXIMATELY 20 MINUTES TO ASSEMBLE.**

**MAKE SURE ALL PARTS ARE FIRMLY TIGHTENED.**

## **UNPACK THE FOUNTAIN**

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS IN THE PACKAGE: FOUNTAIN BODY, UPPER LID, LOWER LID, RESERVOIR, (2) SUBMERSIBLE HALOGEN BULBS, (6) SCREWS, (6) WASHERS, METAL FRAME, A BAG OF RIVER STONES, RUBBER HOSE, TRANSFORMER AND SUBMERSIBLE PUMP. TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE.

## **FOUNTAIN ASSEMBLY**

1. PLACE PUMP FLAT IN RESERVOIR AND ATTACH RUBBER HOSE TO PUMP.
2. PLACE FOUNTAIN BODY INTO RESERVOIR, THEN SECURE WITH (2) WASHERS AND (2) SCREWS.
3. JOIN THE RUBBER HOSES TOGETHER FROM BACK OF FOUNTAIN BODY.
4. FEED LIGHT POWER CORD UP THROUGH HOLE IN FOUNTAIN BODY AND WORKING UPWARDS TOWARD TOP OF TUBE.
5. ATTACH BULB TO BULB CLIP ON BOTTOM OF UPPER LID.
6. PLACE UPPER LID ONTO TOP OF FOUNTAIN BODY.

**FOR TABLE TOP APPLICATIONS: SKIP TO STEP #10.**

## **FOR WALL MOUNTED APPLICATIONS:**

7. PLACE THE METAL FRAME ON BACK OF FOUNTAIN AS SHOWN, THEN SECURE WITH (4) WASHERS AND (4) SCREWS.
8. IT IS RECOMMENDED TO CONTACT YOUR LOCAL HARDWARE PROFESSIONAL TO SELECT THE MOST APPROPRIATE TYPE OF SCREWS AND ANCHORS FOR YOUR PARTICULAR WALL. FOR MOST SECURE INSTALLATION IT IS RECOMMENDED TO MOUNT THE FOUNTAIN DIRECTLY INTO A WALL STUD.
9. MOUNT THE FOUNTAIN TO WALL.
10. FILL RESERVOIR WITH 1.1 GALLONS WATER TO COMPLETELY SUBMERSE PUMP. (DISTILLED WATER IS RECOMMENDED BY US IN THE FOUNTAIN TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD UP.)
11. PLACE LOWER LID ONTO RESERVOIR TO COVER THE ENTRY, THEN PLACE RIVER STONES ONTO RESERVOIR.
12. JOIN THE CONNECTORS TOGETHER.
13. PLUG THE TRANSFORMER INTO SOCKET AND TURN ON AT SWITCH, YOUR FOUNTAIN IS READY FOR USE.
14. YOU CAN REGULATE THE FLOW OF WATER BY ADJUSTING THE WATER FLOW CONTROL VALVE.

## **TROUBLE SHOOTING:**

1. IF YOUR FOUNTAIN DOES NOT WORK, CHECK PLUG AT THE SOCKET. MAKE SURE THE PLUG IS FULLY AND PROPERLY INSERTED INTO THE WALL OUTLET.
2. NEXT CHECK TO MAKE SURE THE OUTLET IS POWERED.
3. IF THE FOUNTAIN STILL DOES NOT WORK, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.

## **SPLASHING DISCLAIMER:**

SPLASHING MAY OCCUR WHEN FOUNTAIN IS INITIALLY TURNED ON. PROTECT SURROUNDING SURFACES AS NEEDED.

## **IMPORTANT PUMP INFORMATION:**

PUMP MUST BE FULLY SUBMERSED IN WATER WHILE OPERATING.

## **WATER:**

TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD UP THE USE OF DISTILLED WATER IS RECOMMENDED.

## **WARNING:**

\* ONCE A WEEK INSPECT FOUNTAIN, FLOOR AND ADJACENT WALL FOR MOISTURE BUILD-UP AND CLEAN AS NECESSARY. THIS IS ESPECIALLY IMPORTANT FOR HUMID ENVIRONMENTS.

\*\* THIS FOUNTAIN IS RATED FOR INDOOR USE ONLY.

\*\*\* THIS UNIT MUST BE CONNECTED TO A SUPPLY CIRCUIT THAT IS PROTECTED BY A GROUND FAULT CIRCUIT INTERRUPTER (GFCI). THE GFCI SHOULD BE TESTED ON A ROUTINE BASIS. TO TEST THE GFCI, PUSH THE TEST BUTTON. THE GFCI SHOULD INTERRUPT POWER. PUSH THE RESET BUTTON. POWER SHOULD BE RESTORED. IF THE GFCI FAILS TO OPERATE IN THIS MANNER, THE GFCI IS DEFECTIVE.